



## **FTI AIR AODD MODELS FT20P & FT20V**

### **Assembly, Installation, & Operation Manual**

P/N 109690 R8



**Record your Model and Serial Number here.**

**MODEL NUMBER** \_\_\_\_\_

**SERIAL NUMBER** \_\_\_\_\_



A DIVISION OF FINISH THOMPSON INC.  
921 Greengarden Rd • Erie, PA 16501 USA  
Ph: 814-455-4478 • Fax: 814-455-8518  
[www.ftiair.com](http://www.ftiair.com)

## EU Declaration of Conformity



FTI Air hereby declares that the following machine(s) fully comply with the applicable health and safety requirements as specified by the EC Directives listed. The complete product complies with the provisions of the EC Directive on machinery safety.

This declaration is valid provided that the devices are fully assembled and no modifications are made to these devices.

### Type of Device:

Air Operated Double Diaphragm Pumps

### Models:

FT025P, FT025V, FT025C, FT05P, FT05V, FT05A, FT05S,  
FT10P, FT10V, FT10A, FT10S, FT15P, FT15V, FT15A, FT15S, FT15ZP, FT15ZV, FT15ZA, FT15ZS,  
FT20P, FT20V, FT20A, FT20S, FT30A & FT30S

### EC Directives:

Machinery Safety (2006/42/EC)

### Applied Harmonized Standards:

EN ISO 12100

### Manufacturer:

FTI Air A Division of Finish Thompson, Inc.  
921 Greengarden Road  
Erie, Pennsylvania 16501-1591 U.S.A

Signed,

President

23 May 2019

Person(s) Authorized to Compile Technical File: FTI Air GmbH  
Otto-Hahn-Strasse 16  
Maintal, D-63477 DEU  
Telephone: 49 (0)6181-90878-0

# Table of Contents

## Important Information - READ ME FIRST

|                                    |     |
|------------------------------------|-----|
| Export Regulation Notice .....     | 4   |
| Chemical Reaction Disclaimer ..... | 4   |
| Safety Precautions .....           | 4-5 |

## Pump Specifications

|                                                      |   |
|------------------------------------------------------|---|
| Materials Profiles.....                              | 5 |
| Model Number Explanation & Example Part Numbers..... | 6 |
| Dimensional Drawing.....                             | 6 |
| Performance Curve.....                               | 7 |
| Specifications.....                                  | 7 |

## Installation/Operation

|                           |   |
|---------------------------|---|
| Installation Drawing..... | 8 |
| Precautions.....          | 8 |
| Troubleshooting.....      | 9 |

## Maintenance

|                                                   |       |
|---------------------------------------------------|-------|
| Recommended Tools .....                           | 9     |
| Wet End Servicing .....                           | 9     |
| Disassembly .....                                 | 10-11 |
| Reassembly .....                                  | 12-16 |
| Air End Servicing .....                           | 16    |
| Shaft Bushing & O-ring Replacement.....           | 16-18 |
| Air Valve O-ring Replacement.....                 | 18-19 |
| Valve & Muffler Gasket Replacement.....           | 19-20 |
| Air Valve Slide, Plate, & Gasket Orientation..... | 20    |
| Replacement Air Valve Kit Installation.....       | 21    |
| Exploded View .....                               | 21    |
| Spare Parts List.....                             | 21-23 |

|                |    |
|----------------|----|
| Warranty ..... | 24 |
|----------------|----|

# Important Information- Read Me first

## IMPORTANT NOTICE

U.S. Export Administration Regulations, pursuant to ECCN 2B350, prohibit the export or re-export to certain enumerated countries of air operated double diaphragm pumps in which all wetted materials are constructed from fluoropolymers without first applying for and obtaining a license from the U.S. Bureau of Industry and Security(BIS). This affects all FTI AIR pumps constructed from PVDF with PTFE balls and diaphragms. Please contact the BIS ([www.bis.doc.gov](http://www.bis.doc.gov)) or FTI Air with questions regarding the Regulations or a list of the countries to which they apply.

## Chemical Reaction Disclaimer

The user must exercise primary responsibility in selecting the product's materials of construction which are compatible with the fluid(s) that come(s) in contact with the product. The user may consult FTI Air (manufacturer) and a manufacturer's representative/distributor agent to seek a recommendation of the product's material of construction that offers the optimum available chemical compatibility.

However neither manufacturer nor agent shall be liable for product damage or failure, injuries, or any other damage or loss arising out of a reaction, interaction or any chemical effect that occurs between the materials of the product's construction and fluids that come into contact with the product's components.

## Unpacking & Inspection

Unpack the pump and examine for any signs of shipping damage. If damage is detected, save the packaging and notify the carrier immediately.

To install the pump, follow the installation instructions provided

## Safety Precautions

**⚠ WARNING:** Never use a natural polypropylene or natural PVDF pump with flammable or combustible fluids/materials.

**⚠ WARNING:** FTI Air maximum temperature limits are based upon the material's mechanical stress only. Maximum temperature is application dependent. Consult a chemical resistance guide or the chemical manufacturer for chemical compatibility and temperature limits.

**⚠ WARNING:** Chemical Hazard. This pump is used for transferring many types of potentially dangerous chemicals. Always wear protective clothing, eye protection and follow standard safety procedures when handling corrosive or personally harmful materials. Proper procedures should be followed for draining and decontaminating the pump before disassembly and inspection of the pump. There may be small quantities of chemicals present during inspection.

**⚠ WARNING:** Hot surfaces. FTI Air pumps are capable of handling liquids with temperatures as high as 220°F (104°C). This may cause the outer areas of the pump to become hot as well and could cause burns.

**⚠ WARNING:** If a diaphragm rupture occurs, material being pumped may be forced out of the air exhaust. Proper care should be taken, always wear protective clothing, eye protection & follow standard safety procedures.

**⚠ WARNING:** When pumping hazardous liquids, or operating the pump in an enclosed room, it is important to pipe the exhaust air to a safe area.

**⚠ WARNING:** For polypropylene or PVDF pumps do not exceed 100 psig (6.9 bar) air supply & 120 psig (8.3 bar) for aluminum and stainless steel.

**⚠ CAUTION:** Before attaching air supply to pump to make sure all airline debris is clear. It is recommended to use a minimum 5μ (micron) air filter before the air valve.

**⚠ CAUTION:** Before maintenance or repair, close the compressed air line supply valve, bleed the pressure and disconnect air line from the pump. Discharge line may also be pressurized. Any pressure must be relieved prior to servicing. Isolate and remove suction / discharge lines & drain the pump. Note that flooded suction systems could be subject to significant leaking through the exhaust before suction isolation valve is closed.

**⚠ CAUTION:** If pump is used with materials that tend to solidify or settle, the pump should be flushed after each use to prevent damage.

**⚠ WARNING:** Pump exhaust may be loud and contain particles. Wear appropriate ear and eye protection. In the event of a diaphragm rupture material can be forced out of the air exhaust muffler. If product is hazardous or toxic, pipe exhaust to appropriate safe area.

**⚠ CAUTION:** Do not over-tighten the air inlet fitting or muffler. Too much torque could damage the air valve or muffler plate.

**⚠ CAUTION:** Use only genuine FTI Air replacement parts to assure compatibility & longest service life.

**⚠ CAUTION:** Check the temperature limits for all wetted components when choosing pump materials. See table below.

**⚠ EXPLOSION HAZARD!** FTI Air pumps with standard materials of construction should not be used with halogenated hydrocarbons. Halogenated hydrocarbon solvents can cause explosion when used with aluminum components in a closed (pressurized) system. FTI Air pumps with standard materials of construction contain aluminum components and will be affected by halogenated hydrocarbon solvents. 1-1-1 Trichloroethane and Methylene Chloride are the most common halogenated hydrocarbons. However, other halogenated hydrocarbon solvents are suspect if used either as part of paint or adhesive formulation, or for clean-up flushing.

For applications that may involve halogenated hydrocarbons, contact FTI Air to discuss the availability of alternative pump materials of construction.

## Material Profiles

| Material               | Chemical Composition                                                          | Description                                                                                                                                                             | Operating Temperature           |               | Relative Cost |
|------------------------|-------------------------------------------------------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------|---------------------------------|---------------|---------------|
|                        |                                                                               |                                                                                                                                                                         | Minimum                         | Maximum       |               |
| <b>Polypropylene</b>   | Pure Polypropylene                                                            | Thermoplastic that is resistant to alkali and strong acids.                                                                                                             | 32°F (0°C)                      | 158°F (70°C)  | \$            |
| <b>PVDF</b>            | Pure Polyvinylidene Fluoride                                                  | Strong fluoropolymer with excellent chemical resistance.                                                                                                                | 10°F (-12°C)                    | 220°F (104°C) | \$\$\$        |
| <b>Stainless Steel</b> | 316 Stainless Steel                                                           | Excellent chemical resistance, high tensile and impact strength, abrasion resistant.                                                                                    | Limited by other materials used |               | \$\$          |
| <b>Aluminum</b>        | ADC 12, LM24, LM25                                                            | Moderate chemical resistance with good impact strength and abrasion resistance.                                                                                         | Limited by other materials used |               | \$            |
| <b>Buna</b>            | Acrylonitrile-butadiene Rubber                                                | General purpose elastomer. Resistant to oil, water, solvent, and hydraulic fluid.                                                                                       | 10°F (-12°C)                    | 190°F (88°C)  | \$            |
| <b>EPDM</b>            | Ethylene Propylene Diene Rubber                                               | Good resistance to mild acids, detergents, alkalis, ketones, and alcohols.                                                                                              | -40°F (-40°C)                   | 250°F (121°C) | \$            |
| <b>FKM</b>             | Fluorocarbon Rubber                                                           | Good chemical resistance and high temperature properties. Resistant to most acids, aliphatic, aromatic, and halogenated hydrocarbons, oils, grease, and fuels.          | -40°F (-40°C)                   | 350°F (177°C) | \$\$          |
| <b>Neoprene</b>        | Chloroprene Rubber                                                            | General purpose elastomer with good resistance to moderate chemicals, oils, grease, solvents, and some refrigerants.                                                    | 0°F (-18°C)                     | 212°F (100°C) | \$            |
| <b>Santoprene™</b>     | Fully cured EPDM rubber particles encapsulated in a polypropylene (PP) matrix | Thermoplastic elastomer with good abrasion resistance with chemical resistance to a wide range of solvents and chemicals. Injection molded with no fabric layer.        | -40°F (-40°C)                   | 225°F (107°C) | \$            |
| <b>Hytrel®</b>         | Thermoplastic polyester elastomer                                             | Combines resistance and flexibility of elastomers with the strength of plastics. Resistant to acids, bases, amines, and glycols. Injection molded with no fabric layer. | -20°F (-29°C)                   | 220°F (104°C) | \$            |
| <b>Polyurethane</b>    | Polyester Urethane                                                            | Thermoplastic that exhibits excellent abrasion resistance. Injection molded with no fabric layer.                                                                       | 32°F (0°C)                      | 150°F (66°C)  | \$            |
| <b>PTFE</b>            | Polytetrafluoroethylene                                                       | Chemically inert. Resistant to a wide range of chemicals.                                                                                                               | 40°F (4°C)                      | 225°F (107°C) | \$\$          |
| <b>FEP</b>             | Fluorinated Ethylene Propylene                                                | Similar to PTFE in composition and chemical resistance. Used to encapsulate FKM o-rings for superior chemical resistance.                                               | 40°F (4°C)                      | 225°F (107°C) | \$\$          |

Santoprene™ is a registered tradename of Exxon Mobil Corp.

Hytrel® is a registered tradename of Dupont™

## Model Number Explanation & Example Part Numbers

PART #

|        |           |                 |   |                     |                    |   |                    |                  |                  |   |             |   |            |                  |          |
|--------|-----------|-----------------|---|---------------------|--------------------|---|--------------------|------------------|------------------|---|-------------|---|------------|------------------|----------|
| XX     | XX        | X               | - | X                   | -                  | X | X                  | X                | -                | X | X           | - | X          |                  |          |
| Series | Pump Size | Wetted Material |   | Non-wetted Material | Air Valve Material |   | Diaphragm Material | Check Valve Ball | Check Valve Seat |   | Seat O-ring |   | Connection | Porting Location | Specials |

### Series\*

FT - Pump End  
FW - Wet End

### Pump Size\*

20 - 2"

### Wetted Materials\*

P - Polypropylene, FDA  
V - PVDF

### Non-wetted Materials

P - GFRPP

### Air Valve Materials

A - Aluminum

P - GFRPP

### Diaphragm Materials\*

N - Neoprene  
B - Buna-N, FDA  
E - EPDM  
F - FKM  
R - Santoprene  
H - Hytrel  
U - Polyurethane

### Check Valve Ball Materials\*

N - Neoprene  
B - Buna-N  
E - EPDM  
S - 316SS, FDA  
W - Weighted PTFE, FDA

1 - PTFE/Neoprene  
2 - PTFE/Santoprene  
3 - PTFE/BUNA, FDA  
4 - PTFE/Santoprene, FDA  
5 - Santoprene, FDA  
6 - Hytrel, FDA

F - FKM  
R - Santoprene  
T - PTFE, FDA  
5 - Santoprene, FDA

### Check Valve Seat Materials\*

P - Polypropylene, FDA V - PVDF

### Check Valve Seat O-Ring Materials\*

B - Buna-N U - Polyurethane  
F - FKM C - FEP/FKM, FDA  
R - Santoprene

### Connection

F - ANSI/DIN/ISO Flange

### Porting location

1 - End (standard)

### Specials


M1 - Metal muffler M2 - Oversized metal muffler  
P1 - Halogenated hydro-carbon compatible

\*Required for wet end


Example Pump P/N's: FT20P-PP-RRPR-F1, FT20P-PA-BBPB-F1, FT20V-PP-1TVC-F1 & FT20V-PA-FFVF-F1

Example Wet End P/N's: FW20P-RRPR, FW20P-BBPB, FW20V-1TVC & FW20V-FFVF

## Dimensional Drawing




## FT20P & FT20V Performance



## Specifications

| Pump Type: Non-Metallic Air Operated Double Diaphragm                 |                                                                                                                                                                                                           |
|-----------------------------------------------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Weight:</b> PP - 67.0 lbs (30.4 kgs)<br>PVDF - 97.5 lbs (44.2 kgs) | <b>Max Suction Lift:</b> Wet - 28 ft H <sub>2</sub> O (8.5 m H <sub>2</sub> O)<br>Dry - Rubber: 13 ft H <sub>2</sub> O (4.0 m H <sub>2</sub> O)<br>PTFE: 9.3 ft H <sub>2</sub> O (2.8 m H <sub>2</sub> O) |
| <b>Air Inlet/Exhaust Size:</b> 3/4" FNPT                              | <b>Max Flow Rate:</b> 154 gpm (583 lpm)                                                                                                                                                                   |
| <b>Max Air Inlet Pressure:</b> 100 psig (6.9 bar)                     | <b>Suction/Discharge Size:</b> 2" ANSI/DIN/ISO 150# flange                                                                                                                                                |
| <b>Max Material Inlet Pressure:</b> 10 psig (0.7 bar)                 | <b>Max Particle Size:</b> 0.35" (8.9 mm)                                                                                                                                                                  |
| <b>Air Consumption @ 100 psi:</b> 100 scfm (170 Nm³/hr)               | <b>Max Outlet Pressure:</b> 100 psig (6.9 bar)                                                                                                                                                            |
| <b>Noise Level:</b> 77 dB(A)                                          | <b>Displacement Per Stroke:</b> 0.31 gal (1.2 liter)                                                                                                                                                      |

## Installation Drawing



PUMP MUFFLER IS ON THE BACK SIDE OF THE PUMP.  
IT CAN BE REMOVED AND EXHAUST CAN BE PIPED TO DESIRED LOCATION.

## Installation / Operation Precautions

### Installation and Start up

Install the pump in a vertical position or it may not prime properly. Pump should be located as close to the product being pumped as possible. Suction line length should be as short as possible and limit the number of fittings. Suction line diameter should not be reduced smaller than the suction diameter of the pump. When using rigid pipe run short sections of flexible hose or flexible connections between the pump & piping. Secure the pump to a suitable surface.

### Air Supply

Connect the pump air inlet to an air supply with sufficient capacity to achieve desired performance. A pressure regulating valve should be installed to ensure air supply pressure does not exceed recommended limits.

### Air Valve Lubrication

No lubrication is required for the air distribution system.

### Fasteners

Re-torque all fasteners before operation. Creep of housing and gasket materials may cause fasteners to loosen. Re-torque all fasteners to the torque specifications listed on the exploded view drawing in this manual.

### Air Inlet & Priming

Pump will start to operate as soon as the shut-off valve is opened. It is recommended to open the shut-off valve slowly at first. Once the pump primes; the shut-off valve can be opened additionally to increase the pump's flow. If the pump is operating but not pumping any liquid see the troubleshooting section for tips & suggestions.

## Accessories

Surge suppressors, spill stops & filter regulators are available and should be used with FTI Air pumps.

## Troubleshooting Tips & Suggestions

### PUMP WILL NOT START OR CYCLE:

- Blocked liquid pipe or hose - Clean out or replace
- Clogged liquid chamber - Remove debris
- Diaphragm shaft bushing / o-ring leak - Replace o-rings
- Air valve carrier not shifting - Inspect, clean, re-oil with 10 wt. air tool oil. (aluminum air valve)
- Air valve carrier not shifting - Inspect, replace seals (polypropylene air valve)

### ERRATIC CYCLING:

- Diaphragm failure - Replace diaphragm
- Valve ball not seating properly, worn or damaged – Inspect, remove debris or replace
- Leak in suction line - Inspect, repair or replace
- Diaphragm shaft bushing / o-ring leak - Replace o-rings
- Air valve carrier not shifting - Inspect, clean, re-oil with 10 wt. air tool oil. (aluminum air valve)
- Air valve carrier not shifting - Inspect, replace seals (polypropylene air valve)
- Over lubrication in air valve - Inspect, degrease, reuse. Adjust lubrication
- Excess moisture in air valve – Inspect, dry, reuse. Consider installing an air dryer
- For aluminum air valves, worn carrier or valve bore – measure carrier and valve bore, diametrical clearance should be between .0020” - .0035”. Replace worn components as needed
- For plastic air valves, worn carrier seals – replace carrier seals if there is no longer interference between seals and valve bore

### PUMP CYCLES BUT WILL NOT PUMP:

- Too much suction lift - Reduce suction lift or fill liquid chambers with liquid
- Leak in suction line - Inspect, repair or replace
- Valve ball not seating properly, worn or damaged - Inspect, remove debris or replace
- Clogged suction pipe or hose - Inspect & clear
- Clogged strainer if used - Inspect & clear
- Diaphragm failure - Replace diaphragm

### PUMPED LIQUID RELEASED FROM AIR EXHAUST

- Diaphragm failure - Replace diaphragm
- Outer plate unthreading - Tighten & re-torque

## Maintenance

### Recommended tools for Servicing Pump

- 13 mm, 15 mm, & 17 mm box wrenches; (2) 30mm socket wrenches, snap ring pliers; 5 & 6 mm hex wrenches, o-ring pick, & torque wrench.

### Wet End Servicing (Installing Wet End Kit)


- Relieve airline pressure and fluid line pressures before conducting maintenance.
- The pump can be drained by turning it upside down and allowing fluid to drain into an appropriate container. Use proper safety equipment when conducting maintenance as internal components may still contain the pumped media.
- Lubricate all stainless steel to stainless steel fasteners to prevent galling. Torque values listed in the back of this manual are for lubricated fasteners.

## Wet End Disassembly


**1** Remove the (8) discharge manifold bolts & washers (items 11 & 12) from the discharge manifold (item 39) using a 17 mm wrench.




**2** The discharge seat o-rings, valve seats, and valve balls (items 14, 15, 16, & 17) can now be accessed and replaced if needed.



**3** Repeat the above steps for the suction manifold (item 13). The seat o-rings, valve seats and valve balls (items 14, 15, 16, & 17) are located in the liquid chambers (item 19).




**4** Remove both liquid chambers by removing the (12) bolts, washers & nuts (items 11, 12, 18 & 27) on each liquid chamber using a 17mm wrench and nuts can be removed using a 15mm wrench. Inspect and replace diaphragms if needed.



**5** To remove the diaphragms (items 21/22), begin by loosening the (2) outer plates (item 20) using two 30 mm wrenches. Use 6-sided sockets or wrenches to prevent damage to the hex portion of the outer plate.



**6** Remove the outer plate, diaphragm(s), and inner plate (items 20, 21/22 & 23) from the side that is loosened. Pull or push the shaft (item 32) and remaining plates and diaphragms out of the center section. If pulling, it may be easier to grip the diaphragm if it is inverted.



**7** To remove the remaining diaphragm(s) (items 21/22) and plates (items 20 & 23) from the shaft (item 32), place the shaft in a vise. Using a 6-sided 30 mm wrench, remove the remaining diaphragm(s) and plates.



After performing required maintenance, the pump can be reassembled. The pump can also be reassembled using the disassembly instructions in the reverse order as listed above. For detailed assembly instructions, follow the steps in the Wet End Reassembly section beginning on page 12.

## Wet End Reassembly

**1** Slide the center hole of one diaphragm (item 22) over the molded-in bolt of an outer plate (item 20). The air side of the diaphragm is labeled and should face away from the plastic portion of the outer plate.

If the pump is fitted with PTFE diaphragms (item 21), first place a PTFE diaphragm over the molded in bolt of the outer plate (item 20). Then place the backup diaphragm (item 22) on the outer plate. The shape of the PTFE diaphragm and back up diaphragm should roughly conform to one another. See the exploded view drawing for proper orientation.



**2** Place the inner plate (item 23) over the molded-in bolt. Ensure the round recess in the plate faces the diaphragm (item 22).




**3** Place the bump stop (item 31) onto one end of the shaft (item 32).



**4** Apply a couple drops of a medium strength thread locker, such as Loctite® 246, to the molded in outer plate bolt (item 20). Thread the shaft (item 32) onto the molded in bolt until it is snug to the flat back side of the inner plate (item 22).




**5** The shaft (item 32) and shaft o-rings (item 30) should retain the lubricant that was factory applied. If they appear dry, apply a light coat of lithium thickened grease. Avoid over lubrication as it can cause decreased performance of the air distribution system.



**6** Push the shaft (item 32) through the center of the shaft bushing (item 29). It is normal for this to be a tight fit, especially if the shaft and shaft o-rings (item 30) are in good condition.



**7** Place the remaining bump stop (item 31) on the other end of the shaft.



**8** It may be easier to thread the molded in bolt into the shaft if the diaphragm(s) is inverted on one or both sides. This can be done by hand.




**9** The other diaphragm(s) (items 21/22) and inner/outer plates (items 20 & 23) can be installed onto the opposite end of the shaft (item 32).



**10** Tighten and torque the outer plates (item 20). If the pump is fitted with PTFE diaphragms (item 21), it is necessary to restrict their ability to rotate when tightening the outer plates. This can be done by inserting all the liquid chamber bolts (items 12 & 18) through the PTFE diaphragm holes and into the center section (item 35) on each side. This will ensure that the PTFE diaphragm does not obstruct the bolts ability to thread into the center section when the liquid chambers are installed. Remove these bolts once the outer plates are torqued.




**11** Install the liquid chambers (item 19) by placing one side over the diaphragm. Start all bolts, washers & nuts (items 11, 12, 18 & 27) before tightening and torquing. Torque all fasteners in a star pattern. Repeat to install the second liquid chamber. Ensure both chambers are orientated the same and that the inlet and outlet ports are vertical when facing the front of the pump as shown.



**Note:** When installing polytetrafluoroethylene (PTFE) diaphragms, it is important to tighten outer plates simultaneously (turning in opposite directions) to ensure tight fit.


**12** Flip the pump upside down and drop the suction valve balls (item 17) into the liquid chamber (item 19) ball cages.



**13** Place the valve seats (item 16) into the seat counter bores of the liquid chambers (item 19). The o-ring (item 14) gland in the valve seat should be facing away from the valve ball.




**14** Place the manifold o-rings (item 15) into the o-ring gland on the suction manifold (item 39). Place the suction manifold atop the pump and install, tighten and torque the (8) manifold bolts & washers (items 11 & 12).



**15** Stand the pump upright onto the suction manifold feet (item 13). Place the large o-rings (item 15) into the glands in the face of the liquid chambers (item 19) followed by the small o-ring (item 14) in the gland of the valve seats (item 16). Place the valve seats on the liquid chambers with the o-ring down against the liquid chamber.



- 16** Place the valve balls (item 17) on the valve seats and discharge manifold (item 39) atop the components that are stacked on top of the liquid chambers. Install, tighten and torque the (8) manifold bolts & washers (items 11 & 12).



## Air End Servicing (Installing Air End Kit)


### Shaft, Bushing, & O-ring Replacement

- Follow steps 1 – 7 in the Wet End Servicing disassembly section to access the shaft bushing (item 29) and o-rings (items 28 & 30).

- 1** Remove both air chambers by removing the (4) bolts and (4) nuts using a 13mm (or ½”) wrench.



- 2** Remove and set aside the air valve (item 3) using a 6 mm hex wrench (see “Valve & Muffler Gasket Replacement” section for more details). The shaft bushings (item 29) can be removed by placing a large socket between the two bushings. Place an extension into the socket from one side of the center section. Tap with a rubber mallet to remove the bushing. Repeat for the remaining bushing.



**3** Use the supplied grease packets to lightly grease the OD and ID o-rings (items 28 & 30) that come preinstalled in the new shaft bushings supplied in air end kits.



**4** Insert both bushings into the center section. Ensure the bushing is fully installed and the large rib on the outside of the bushing is flat against the center section.



**5** Inspect the shaft (item 32) for damage. It is common for shafts to become grooved during service. Grooving is normally caused by carbonized oil and/or abrasive foreign material getting trapped between the seal and the shaft. Over time, deep grooves can form in the shaft. When that occurs, it is recommended that the shaft be replaced.




**6** After determining if the condition of the shaft is acceptable, ensure both center section o-rings (items 33 & 34) are in place on both sides of the center section.



**7** Install both air chambers (item 26) by placing one side on top of the center section (item 35). Ensure the air path hole of the center section lines up with the through hole in the air chamber. Insert the bolts & washers (items 24 & 25) through the air chamber and center section.



**8** Flip the components over and place the remaining air chamber on the center section. Thread the nuts & washers onto the bolts (items 24, 25 & 40). Tighten and torque the fasteners.




• To rebuild the rest of the pump, follow steps 5 – 16 in the Wet End Servicing – Wet End Reassembly section.

### Air Valve O-Ring Replacement


**1 Plastic Air Valve** - To replace the valve cap o-rings remove the retaining ring (item 8), then pull the valve cap (item 6) straight up. The use of an M8 bolt, vise grip, and pry bars may be necessary. See 1 and 1A pictures below.




**1 Aluminum Air Valve** - To replace the valve cap o-rings (item 5), remove the (3) button head cap screws (item 7) using a 5mm hex wrench. Repeat for the remaining cap.



**2 Plastic Air Valve** - Remove and replace o-rings (item 5). Insert cap (item 6) and push down until groove for the retaining ring is visible. Install retaining ring (item 8). Make sure to lubricate the o-rings prior to inserting into the valve body with a compatible lubricant.




**2 Aluminum Air Valve** - Remove and replace o-ring (item 5). Install cap (item 6), tighten, and torque the valve cap screws (item 7). Repeat for the remaining cap.




### Valve and Muffler Gasket Replacement

**1** Remove the valve body (item 3) by removing the (4) socket head cap screws & lock washers (items 1 & 2) that attach the valve body to the muffler plate (item 38) with a 6mm hex wrench.






**2** Pull the valve body and gasket (items 3 & 36) off the front of the center section (item 35) and the muffler plate gasket, muffler plate and muffler (items 37, 38 & 41) off the back.




**3** Place the new gasket (item 36) on the air valve (item 3) and ensure the slots in the gasket align with the slots in the air valve and valve plate (item 10).


**Air Valve Slide, Plate & Gasket Orientation:** If the valve plate (item 10) and slide valve (item 9) are removed, ensure they are installed in the proper orientation. The flat face of the slide valve sits in the pocket of the valve carrier (item 4) so that the square cut out on the slide valve faces the smooth polished side of the valve plate.




**4** Insert the (4) cap screws (item 1) through the valve body and gasket (items 3 & 36) and place onto the center section (item 35). Ensure the slide valve and valve plate (items 9 & 10) are in place and the valve sits flat on the center section.



**5** Place the muffler gasket (item 37) over the (4) cap screws & lock washers (items 1 & 2) on the back side of the center section (item 35) followed by the muffler plate and muffler (items 38 & 41).




**6** Tighten and torque the (4) cap screws into the muffler plate.



## Replacement Air Valve Kit Installation

1. Remove the valve that is to be replaced by removing the (4) socket head cap screws with a 6 mm hex wrench that attaches the valve body to the muffler plate.
  2. Save the (4) cap screws, (4) lock washers, muffler plate, and muffler. All other valve components can be discarded.
  3. Remove the packing tape that holds the air valve components in place during shipping.
- Follow steps 3 – 6 in the Valve and Muffler Gaskets section of Air End Servicing above.

## Exploded View & Spare Parts List



| ITEM | DESCRIPTION                             | PART NO.             | QTY | KIT   |
|------|-----------------------------------------|----------------------|-----|-------|
| 1    | CAP SCREW, SOCKET HD M8X1.25 X 120MM SS | 109520               | 4   | -     |
| 2    | WASHER, LOCK M8 HIGH-COLLAR SSTL        | 109518               | 4   | -     |
| 3    | VALVE BODY                              | SEE AIR VALVE TABLES |     | V1/V2 |
| 4    | VALVE CARRIER                           | SEE AIR VALVE TABLES |     | V1/V2 |
| 5    | VALVE CAP O-RING                        | SEE AIR VALVE TABLES |     | V1/V2 |
| 6    | VALVE CAP                               | SEE AIR VALVE TABLES |     | V1/V2 |
| 7    | CAP SCREW, SOCKET HD M6X1.0X16MM SS     | SEE AIR VALVE TABLES |     | V2    |
| 8    | RETAINING RING, HO-137 SS               | SEE AIR VALVE TABLES |     | V1/V2 |
| 9    | SLIDE VALVE                             | 109259               | 1   | V1/V2 |
| 10   | VALVE PLATE                             | 109263               | 1   | V1/V2 |
| 11   | WASHER, FLAT 3/8" REG. TYPE B SS        | 109514               | 40  | -     |

| ITEM | DESCRIPTION                                     | PART NO.  | QTY | KIT |
|------|-------------------------------------------------|-----------|-----|-----|
| 12   | CAP SCREW, HEX HD FLNG M10X1.5 X 80MM SSTL      | 109515    | 32  |     |
| 13   | MANIFOLD, SUCTION POLYPROPYLENE, FDA            | 109276    | 1   |     |
|      | MANIFOLD, SUCTION PVDF                          | 109277    |     |     |
| 14   | O-RING, VALVE SEAT, BUNA-N                      | 109308    | 4   | W   |
|      | O-RING, VALVE SEAT, FKM                         | 109323    |     |     |
|      | O-RING, VALVE SEAT, POLYURETHANE                | 109537    |     |     |
|      | O-RING, VALVE SEAT, SANTOPRENE                  | 109538    |     |     |
|      | O-RING, VALVE SEAT, FEP ENCAPSULATED FKM, FDA   | 109536    |     |     |
| 15   | O-RING, MANIFOLD, BUNA-N                        | J104095   | 4   | W   |
|      | O-RING, MANIFOLD, FKM                           | J102389   |     |     |
|      | O-RING, MANIFOLD, POLYURETHANE                  | 109541    |     |     |
|      | O-RING, MANIFOLD, SANTOPRENE                    | 109542    |     |     |
|      | O-RING, MANIFOLD, FEP ENCAPSULATED FKM, FDA     | 109328    |     |     |
| 16   | VALVE SEAT, POLYPROPYLENE, FDA                  | 109293    | 4   | W   |
|      | VALVE SEAT, PVDF                                | 109298    |     |     |
| 17   | VALVE BALL, NEOPRENE (GREEN DOT)                | 109205    | 4   | W   |
|      | VALVE BALL, BUNA (RED DOT)                      | 109209    |     |     |
|      | VALVE BALL, EPDM (BLUE DOT)                     | 109213    |     |     |
|      | VALVE BALL, FKM (WHITE OR SILVER DOT)           | 109217    |     |     |
|      | VALVE BALL, SANTOPRENE (RED BALL)               | 109221    |     |     |
|      | VALVE BALL, SANTOPRENE, FDA (NATURAL)           | 109221-1  |     |     |
|      | VALVE BALL, PTFE, FDA (WHITE BALL)              | 109201    |     |     |
|      | VALVE BALL, 316 STAINLESS STEEL, FDA            | 109370    |     |     |
|      | VALVE BALL, WEIGHTED PTFE, FDA (WHITE BALL)     | 109379    |     |     |
| 18   | CAP SCREW, HEX HD FLNG M10X1.5 X 150MM SSTL     | 109516    | 8   |     |
| 19   | LIQUID CHAMBER, POLYPROPYLENE, FDA              | 109767-11 | 2   |     |
|      | LIQUID CHAMBER, PVDF                            | 109767-12 |     |     |
| 20   | OUTER PLATE, POLYPROPYLENE, FDA                 | 109155    | 2   |     |
|      | OUTER PLATE, PVDF                               | 109158    |     |     |
| 21   | DIAPHRAGM, PTFE, FDA (WHITE) - REQUIRES BACK UP | 109184    | 2   | W   |
| 22   | DIAPHRAGM, NEOPRENE (GREEN DOT)                 | 109901-1  | 2   | W   |
|      | DIAPHRAGM, BUNA-N, FDA (RED DOT)                | 109901-2  |     |     |
|      | DIAPHRAGM, EPDM (BLUE DOT)                      | 109901-3  |     |     |
|      | DIAPHRAGM, FKM (WHITE OR SILVER DOT)            | 109901-4  |     |     |
|      | DIAPHRAGM, SANTOPRENE (RED)                     | 109978    |     |     |
|      | DIAPHRAGM, SANTOPRENE, FDA (NATURAL)            | 109978-1  |     |     |
|      | DIAPHRAGM, HYTREL (CREAM)                       | 109192    |     |     |
|      | DIAPHRAGM, HYTREL, FDA (NATURAL)                | 109192-1  |     |     |
|      | DIAPHRAGM, POLYURETHANE (BEIGE)                 | 109437    |     |     |
| 23   | INNER PLATE - ALUMINUM                          | 109170    | 2   |     |
|      | INNER PLATE - STAINLESS STEEL                   | 109715    |     |     |
| 24   | CAP SCREW, M8X1.25 X 160MM                      | 109473    | 4   |     |
| 25   | WASHER, FLAT M8                                 | 109469    | 8   |     |
| 26   | AIR CHAMBER, GF POLYPROPYLENE                   | 109146    | 2   |     |
| 27   | NUT, HEX HD FLNG M10X1.5 SSTL                   | 109509    | 24  |     |

| ITEM | DESCRIPTION                              | PART NO. | QTY | KIT   |
|------|------------------------------------------|----------|-----|-------|
| 28   | O-RING, BUSHING OD                       | 109420   | 4   | A1/A2 |
| 29   | SHAFT BUSHING W/ O-RINGS (ITEMS 28 & 30) | 109671   | 2   | A1/A2 |
| 30   | O-RING, SHAFT                            | 109424   | 6   | A1/A2 |
| 31   | BUMP STOP                                | 109429   | 2   |       |
| 32   | SHAFT                                    | 109175   | 1   |       |
| 33   | O-RING, CENTER SECTION, LARGE            | 109434   | 2   | A1/A2 |
| 34   | O-RING, CENTER SECTION, SMALL            | 109418   | 2   | A1/A2 |
| 35   | CENTER SECTION, GF POLYPROPYLENE         | 109151   | 1   |       |
| 36   | GASKET, AIR VALVE                        | 109267   | 1   | V1/V2 |
| 37   | GASKET, MUFFLER                          | 109428   | 1   | V1/V2 |
| 38   | MUFFLER PLATE                            | 109271   | 1   |       |
| 39   | MANIFOLD, DISCHARGE, POLYPROPYLENE, FDA  | 109280   | 1   |       |
|      | MANIFOLD, DISCHARGE, PVDF                | 109281   |     |       |
| 40   | NUT, HEX HD M8X1.25                      | 109474   | 4   |       |
| 41   | MUFFLER                                  | 109562   | 1   |       |

| FT20P & FT20V Kits |                                                     |          |
|--------------------|-----------------------------------------------------|----------|
| Kit Key            | Description                                         | Part No. |
| W                  | PARTS SUPPLIED IN WET END KITS                      | -        |
| A1                 | PARTS SUPPLIED IN PLASTIC VALVE AIR END KIT         | 109674   |
| A2                 | PARTS SUPPLIED IN ALUMINUM VALVE AIR END KIT        | 109596   |
| V1                 | PARTS SUPPLIED IN PLASTIC REPLACEMENT VALVE KIT     | 111250   |
| V2                 | PARTS SUPPLIED IN AN ALUMINUM REPLACEMENT VALVE KIT | 109590   |

| PUMPS FITTED WITH GFRPP AIR VALVES<br>FT20_-P-_____-__ |                           |          |     |     |
|--------------------------------------------------------|---------------------------|----------|-----|-----|
| ITEM                                                   | DESCRIPTION               | PART NO. | QTY | KIT |
| 3                                                      | VALVE BODY, GFRPP         | 109904   | 1   | V1  |
| 4                                                      | VALVE CARRIER WITH SEALS  | 111366   | 1   | V1  |
| 5                                                      | VALVE CAP O-RING          | 109580   | 4   | V1  |
| 6                                                      | VALVE CAP, DELRIN         | 109892   | 2   | V1  |
| 8                                                      | RETAINING RING, HO-165 SS | 109645   | 2   | V1  |

| PUMPS FITTED WITH ALUMINUM AIR VALVES<br>FT20_-A-_____-__ |                                 |             |     |     |
|-----------------------------------------------------------|---------------------------------|-------------|-----|-----|
| ITEM                                                      | DESCRIPTION                     | PART NO.    | QTY | KIT |
| 3                                                         | VALVE BODY, ALUMINUM            | SEE ITEM 42 | 1   | V2  |
| 4                                                         | VALVE CARRIER, ALUMINUM         | 109456      | 1   | V2  |
| 5                                                         | VALVE CAP O-RING                | 109416      | 2   | V2  |
| 6                                                         | VALVE CAP, ALUMINUM             | SEE ITEM 42 | 2   | V2  |
| 7                                                         | CAP SCREW, SOC. HD M6X1.0X16 MM | 109513      | 6   | V2  |
| 42                                                        | CONTAINS ITEMS 3, ,4, 5, 6, & 7 | 109593      | 1   | V2  |

| FT20P & FT20V Maximum Torque Settings*                                                                                                                                                                                                           |                      |
|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|----------------------|
| Item #                                                                                                                                                                                                                                           | Torque               |
| 1                                                                                                                                                                                                                                                | 7.9 N-m (70 in-lbs)+ |
| 7                                                                                                                                                                                                                                                | 6.8 N-m (60 in-lbs)  |
| 12                                                                                                                                                                                                                                               | 27 N-m (240 in-lbs)+ |
| 18                                                                                                                                                                                                                                               | 27 N-m (240 in-lbs)+ |
| 20                                                                                                                                                                                                                                               | 81 N-m (720 in-lbs)+ |
| 24                                                                                                                                                                                                                                               | 16 N-m (144 in-lbs)  |
| Asterisk (*) from the exploded view diagram indicates fasteners to be torqued. Stainless steel to stainless steel fasteners should be lubricated to prevent galling. A Plus sign (+) on the above torque values indicates a lubricated fastener. |                      |

## Warranty



FTI Air A Division of Finish Thompson, Inc (manufacturer) warrants this pump product to be free of defects in materials and workmanship for a period of five years from date of purchase by original purchaser. If a warranted defect, which is determined by manufacturer's inspection, occurs within this period, it will be repaired or replaced at the manufacturer's option, provided (1) the product is submitted with proof of purchase date and (2) transportation charges are prepaid to the manufacturer.

Liability under this warranty is expressly limited to repairing or replacing the product or parts thereof and is in lieu of any other warranties, either expressed or implied. This warranty does not apply to normal wear of the product or components. This warranty does not apply to products or parts broken due to, in whole or in part, accident, overload, abuse, chemical attack, tampering, or alteration. The warranty does not apply to any other equipment used or purchased in combination with this product. The manufacturer accepts no responsibility for product damage or personal injuries sustained when the product is modified in any way. If this warranty does not apply, the purchaser shall bear all cost for labor, material and transportation.

Manufacturer shall not be liable for incidental or consequential damages including, but not limited to process down time, transportation costs, costs associated with replacement or substitution products, labor costs, product installation or removal costs, or loss of profit. In any and all events, manufacturer's liability shall not exceed the purchase price of the product and/or accessories



### **FINISH THOMPSON INC. - HEADQUARTERS**

921 Greengarden Road | Erie, PA 16501  
800.934.9384 | ph 814.455.4478 | fx 814.455.8518  
email [fti@finishthompson.com](mailto:fti@finishthompson.com)

### **FINISH THOMPSON GMBH- EUROPE CENTER**

Otto-Hahn-Strasse 16 | Maintal, D-63477 Germany  
49 (0)6181-90878-0 | fx 49 (0)6181-90878-18  
email [europecenter@finishthompson.com](mailto:europecenter@finishthompson.com)